~ Descaling Nespresso Vertuo ~

A "descaling alert" exists on the Vertuo machine. When you see the light around the button on the top of the machine turn Red-Green simultaneously it is time to descale your machine. <u>*The descaling process will take around 20 minutes.*</u>

- Turn the machine ON by pushing the button on top.
- Open the machine head by pushing the front lever upwards and let the used coffee capsule be ejected.
- Close the machine by pushing the front lever down.
- Turn the machine OFF by pushing the front lever down for 3 seconds.
- Remove the cup support and used capsule container.
- Fill the water tank with one (1) package of Nespresso Descaling agent and add a minimum of 0.5L (17 oz.) of water.
- To enter the "Descaling" mode, push the button on top and front lever down at the same time for 3 seconds.
- An ORANGE steady light around the button on top indicates entry into the Special Functions menu.
- Press the front lever down once to enter "Descaling" mode.
- Place a container of at least 0.8L (27 oz) under coffee outlet.
- Push the button on top to start descaling.
- An ORANGE light will blink during the entire descaling process.
  - (Note: The descaling process can be stopped any time by pushing the button on top).
  - <u>Let the water tank with descaling agent completely run dry; when dry the machine stops automatically.</u>
- When descaling is over it will then be necessary to do a rinsing cycle.
- To do so, empty, clean, and rinse the water tank thoroughly.
- Refill the water tank with fresh water and repostion it on the machine before starting the rinsing phase.
- Push the button on top when you are ready.
  - <u>Let the water tank with rinsing water completely run dry.</u>
- The machine will stop automatically when rinsing is done, and the ORANGE light will blink once every 2 seconds.
- To exit this mode, press the button on top and front lever down at the same time for 3 seconds.
- <u>Let the machine cool down for 10 minutes.</u>
- Fill the water tank with fresh drinking water and re-attach the cup support.
- Your machine is now ready to use.